

SPARE PARTS

备品备件



绝缘座块 Socket Interior
编号/Code: S32A-1
图号NO.: NF6.670.056



绝缘座块 Socket Interior
编号/Code: S32A-2
图号NO.:



绝缘座块 Socket Interior
编号/Code: S32A-3
图号NO.: NF6.670.000



绝缘座块 Socket Interior
编号/Code: S32A-4
图号NO.: NF6.604.006



绝缘座块 Socket Interior
编号/Code: S32A-5
图号NO.: NF6.670.004



绝缘座块 Socket Interior
编号/Code: S32A-5/5
图号NO.: NF8.074.004



绝缘座块 Socket Interior
编号/Code: S32A/6
图号NO.: NF8.074.000




插座面板 Socket Panel
编号/Code: S32A-P
图号NO.: NF5.568.002



操作手柄 Handle
编号/Code: SH-S
图号NO.: NF8.333.006



操作手柄 Handle
编号/Code: SH-P
图号NO.: NF8.333.004



插座端盖 Bayonet Cap
编号/Code: DC-S
图号NO.: NF6.171.002



插座端盖 Bayonet Cap
编号/Code: DC-P
图号NO.: NF6.171.003



绝缘座块 Socket Interior
编号/Code: C32A
图号NO.: NF6.670.012



绝缘座块 Plug Interior
编号/Code: P32A
图号NO.: NF6.670.011



手柄轴 Handle Axle
编号/Code: LW-A
图号NO.: NF8.300.004



手柄轴 Handle Axle
编号/Code: LW-AN/AB
图号NO.: NF6.300.010



塑壳断路器 Circuit Breaker
编号/Code: BZMD1
图号NO.:



塑壳断路器 Circuit Breaker
编号/Code: NF63-CW / HW
图号NO.:



塑壳断路器 Circuit Breaker
编号/Code: XS50NB
图号NO.:



转换开关 Rotary Switch
编号/Code: LW-3P
图号NO.: NF6.618.004